




TECHNICAL INFORMATION

Models No. ▶ DGA404, DGA454, DGA504

Description ▶ 18V Cordless Angle Grinders



CONCEPT AND MAIN APPLICATIONS

The subject models are cordless angle grinders powered by 18V Li-ion battery, and equipped with highly enhanced Brushless DC motor compared to the current models DGA402/ DGA452.

A built-in controller changes the cutting speed automatically according to load condition, enabling users to obtain high speed rotation on light duty application/ high torque on heavy duty application.

Note: BL1815 is not compatible.

Dimensions: mm (")		
Length (L)*1	All	362 (14-1/4)
Width (W)	DGA404	117 (4-5/8)
	DGA454	130 (5-1/8)
	DGA504	140 (5-1/2)
Height (H)	DGA404	140 (5-1/2)
	DGA454, DGA504	145 (5-3/4)

*1 With BL1830/ BL1840/ BL1850

Specification

Specification		Model	DGA404	DGA454	DGA504
Battery	Voltage: V		18		
	Capacity: Ah		1.5, 2.0, 3.0, 4.0, 5.0		
	Cell		Li-ion		
	Energy capacity: W		27, 36, 54, 72, 90		
	Charging time (approx.): min.		15, 18, 22, 36, 45 with DC18RC		
Wheel size: mm (")	Diameter		100 (4)	115 (4-1/2)	125 (5)
	Hole diameter		16 (5/8)	22.23 (7/8)	
	Max. thickness		6 (1/4)		
No load speed: min. ⁻¹ = rpm			8,500		
Switch type			Slide		
Electronic control	Overload warning lamp		No		
	Electronic current limiter		Yes		
	Soft start		Yes		
	Anti-restart function		Yes		
Battery fuel gauge			Yes		
Soft grip			Yes		
Weight according to EPTA-Procedure 01/2003: kg(lbs)*2			2.4 (5.3)	2.5 (5.5)	2.5 (5.6)

*2 With 3.0Ah battery

Standard equipment

- Lock nut wrench 1
- Side grip 1
- Depressed center grinding wheel 1 (100mm for DGA404, 115mm for DGA454, 125mm for DGA504)
- Battery cover 1 (except -Z- model)
- Plastic carrying case 1 (except -Z- model)
- Charger DC18RC 1 (except -Z- model)
- Li-ion battery BL1830 or BL1840 2 (except -Z- model)

Note: The standard equipment may vary by country or model variation.

Optional accessories

- | | | | |
|-------------------------|-------------------------|--------------------------------|------------------------|
| Depressed center wheels | Abrasive cut off wheels | Charger DC24SC | Li-ion battery BL1815N |
| Rubber pads | Toolless wheel covers | Automotive charger DC18SE | Li-ion battery BL1820 |
| Abrasive discs | Sanding lock nuts | Four port multi charger DC18SF | Li-ion battery BL1830 |
| Wire brushes | Fast charger DC18RC | | Li-ion battery BL1840 |
| Diamond wheels | Fast charger DC18SD | | Li-ion battery BL1850 |

► Repair

CAUTION: Repair the machine in accordance with “Instruction manual” or “Safety instructions”.

[1] NECESSARY REPAIRING TOOLS


Code No.	Description	Use for
1R004	Retaining ring pliers ST-2	removing/ assembling Ring spring 11
1R027	Bearing setting pipe $\phi 18$ - $\phi 10.2$	pressfitting Rotor
1R029	Bearing setting pipe $\phi 23$ - $\phi 15.2$	pressfitting Spiral bevel gear 37
1R034	Bearing setting plate $\phi 12.2$	
1R045	Gear extractor (large)	removing Rotor
1R258	V block	removing Spiral bevel gear 37
1R268	Spring pin extractor M3	disassembling Shaft lock mechanism
1R269	Bearing extractor (small)	removing Ball bearing 607LLB/ 696ZZ
1R280	Round bar for arbor $\phi 6$ -50	removing Spiral bevel gear 37
1R286	Round bar for arbor $\phi 12$ -50	removing Ball bearing 629LLB
1R291	Retaining ring S and R pliers	removing Retaining ring R-32

[2] LUBRICATION

Apply the following grease to protect parts and product from unusual abrasion. (Fig. 1)

Item No.	Description	Portion to lubricate	Lubricant	Amount
⑤	O ring 26	Inner periphery that appears from Gear housing cover	Makita grease SG. No.0 ◀	9g
⑦	Spiral bevel gear 10	Gear teeth in the gear room of Gear housing		a little

Fig. 1



► **Repair**

[3] DISASSEMBLY/ASSEMBLY

[3]-1. Rotor, Ball bearing 629LLB/ 607LLB, Spiral bevel gear 10

DISASSEMBLING

- (1) Remove Gear housing cover with Rotor section from Motor housing. (Figs. 2, 3 and 4)
- (2) Disassemble Rotor section. (Fig. 5)

Fig. 2




Fig. 3




Fig. 4






Fig. 5



▶ Repair

[3] DISASSEMBLY/ASSEMBLY

[3]-1. Rotor, Ball bearing 629LLB/ 607LLB, Spiral bevel gear 10 (cont.)

DISASSEMBLING

(3) Disassemble Gear housing cover and Rotor section. (Figs. 6 and 7)

Fig. 6





Fig. 7



Caution for Handling of Rotor

When handling or storing multiple Rotors, be sure to keep a proper distance between Rotors as shown in Fig. 8 because Rotor is a strong magnet, failure to follow this instruction could result in:

- Finger injury caused by pinching between Rotors pulling each other.
- Magnetic loss of Rotors or damage on the magnet portion of Rotor.

(Fig. 9)

Fig. 8





Fig. 9



► **Repair**

[3] DISASSEMBLY/ASSEMBLY

[3]-1. Rotor, Ball bearing 629LLB/ 607LLB, Spiral bevel gear 10 (cont.)

ASSEMBLING

Assemble by reversing the disassembly procedure.

Note: Be careful about the points shown in **Figs. 10, 11 and 12.**

Fig. 10




Fig. 11





Fig. 12



► Repair

[3] DISASSEMBLY/ASSEMBLY

[3]-2. Spiral bevel gear 37, Ball bearing 696ZZ and Ball bearing 6201DDW

DISASSEMBLING

Note: The subject parts can be removed without disassembling Motor section.
Disassemble Bearing box section as drawn in **Fig. 13** to **Fig. 19**.

Fig. 13




Fig. 14




Fig. 15




Fig. 16




Fig. 17




Fig. 18





Fig. 19



► Repair

[3] DISASSEMBLY/ASSEMBLY

[3]-2. Spiral bevel gear 37, Ball bearing 696ZZ and Ball bearing 6201DDW (cont.)

ASSEMBLING


Assemble by reversing the disassembly procedure.

Note: When Spindle is pressfit into Spiral bevel gear 37:

1. insert the thread of Spindle into the hole of 1R034 to receive the stepped portion of Spindle on 1R034.
2. put 1R029 on the area around the center hole of Spiral bevel gear 37 and then press it down.

See Fig. 20.

Fig. 20



[3]-3. Shaft lock section

DISASSEMBLING

- (1) According to Fig. 13 in the previous page, remove Bearing box from Motor housing.
- (2) Disassemble Shaft lock section as drawn in Figs. 21 and 22.

Fig. 21





Fig. 22



ASSEMBLING

Assemble by reversing the disassembly procedure.

► **Repair**

[3] DISASSEMBLY/ASSEMBLY


[3]-4. Assembling of Stator complete

Refer to **Figs. 23 and 24.**

Fig. 23



Fig. 24



► **Repair**

[3] DISASSEMBLY/ASSEMBLY

[3]-5. Assembling of Switch knob and Switch lever

Refer to the following and next pages. (Figs. 25, 26, 27, and 28)

Fig. 25




Fig. 26





Fig. 27



► Repair





[3] DISASSEMBLY/ASSEMBLY

[3]-5. Assembling of Switch knob and Switch lever (cont.)

Fig. 28


Insert one end of Pin 2 into the hole of Housing L. and put the one end of Torsion spring 2 on the rib of Housing L. (See below for the detail.)
The other end of Pin 2 should be inserted into the hole of Housing R.

Place the top projection on the reverse side of Switch knob into the groove of Housing L. (See below for the detail.)




▶ **Circuit diagram**

Fig. D-1



► **Wiring diagram**

Fig. D-2




▶ Trouble shooting

Whenever you find any trouble in your machine, first, refer to this list to check the machine for solution.

Note in Repairing

- (1) Use the full charged battery which has the star mark. (Fig. D-3)
- (2) Check the functions by repeating 10 times.
- (3) When Housing is disassembled, check the following conditions: mechanical trouble (lock or wrong setting etc.) poor connection of Connectors, Terminals and screws, lead wire breakage and pinching, wrong contact between Battery and Terminal



Fig. D-3



Check List for Trouble Shooting (Fig. D-4)

Check the items from the top of the following list. (Descriptions of the items are referred to Circuit diagram in Fig. D-1.)

Fig. D-4

Symptom	Cause	Corrective action
When you test with Digital tester (1R402), the proper value is obtained. (Refer to the next page.) In case the tester is not ready, go to "Yes"	No → Controller is broken.	Replace Stator complete.
Yes → Mode lamp is on. 	Yes → Mechanical problem happens.	Identify the mechanical problem and repair or replace the part(s).
	Yes → Controller is broken.	Replace Stator complete.
No → All 3 stages of Battery power remaining lamp are on. 	No → Controller is broken.	Replace Stator complete.
Yes → The machine does not have any trouble.		
Yes → Motor runs when the machine is switched on. Try 10 times. In case of running inconstantly, go to "No".	Connectors are in incomplete connection.	Connect them firmly.
	Lead wires are broken.	Locate the incomplete connection and repair or replace them.
	Switch is broken.	Replace Switch.
No → 1 or 2 stages of Battery power remaining lamp is/are on.	Terminals are broken.	Replace the parts whose terminals are broken.
	Controller is broken.	Replace Stator complete.
Yes → Unusual behavior occurs during work./ Rotor is rubbed Stator complete.	Connectors are in incomplete connection.	Connect them firmly.
	Lead wires are broken.	Locate the incomplete connection and repair or replace them.
	Controller is broken.	Replace Stator complete.
	Roter is broken.	Replace Rotor
No →	Stator complete is broken.	Replace Stator complete.

▶ Trouble shooting

Test for recognizing the trouble on Stator complete

(1) Set Digital tester (1R402) in the diode mode ($\rightarrow|+$ mark on the tester: Refer to **Fig. D-5.**)

(2) Remove Battery, and then turn on Switch. (**Fig. D-6**)

(3) Attach Black tester bar to Plus terminal of Battery terminal.

Attach Red tester bar to Minus terminal of Battery terminal. (**Fig. D-7.**)

Note: Be careful not to reverse them. The reverse attachment could spoil the test.

(4) Wait until the Tester shows the value without fluctuation. There is no fault on Stator complete if the tester indicates **within 0.8V plus/minus 0.1V.**

If Tester indicates 0V or 0.4V approximately, Stator complete is out of order.

Replace Stator complete with new one.

Fig. D-5



Fig. D-6




Fig. D-6

